



Teknisk informasjon



Description	Article no.	Datablad	Fotometri	Installation instruction	EC-Declaration
ALICE LED FL IP65 10W 840	96 666 073	Datablad	Fotometri	Installation instruction	EC-Declaration
ALICE LED FL IP65 30W 840	96 666 074	Datablad	Fotometri	Installation instruction	EC-Declaration
ALICE LED FL IP65 50W 840	96 666 075	Datablad	Fotometri	Installation instruction	EC-Declaration
ALICE LED FL IP65 100W 840	96 666 076	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 150 LED DL 1000 830	96 628 352	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 150 LED DL 1000 840	96 628 353	Datablad		Installation instruction	EC-Declaration
AMY 100 LED DL 800 830	96 665 583	Datablad		Installation instruction	EC-Declaration
AMY 100 LED DL 800 840	96 665 584	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 150 LED DL 1500 830	96 665 585	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 150 LED DL 1500 840	96 665 586	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 200 LED DL 2000 830	96 665 587	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 200 LED DL 2000 840	96 665 588	Datablad		Installation instruction	EC-Declaration
AMY 150 LED DL 1500 830 E3	96 665 844	Datablad		Installation instruction	EC-Declaration
AMY 150 LED DL 1500 840 E3	96 665 845	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 200 LED DL 2000 830 E3	96 665 846	Datablad		Installation instruction	EC-Declaration
AMY 200 LED DL 2000 840 E3	96 665 847	Datablad	Fotometri	Installation instruction	EC-Declaration
AMY 150 LED DL 1000 830 E3	96 665 848	Datablad		Installation instruction	EC-Declaration
AMY 150 LED DL 1000 840 E3	96 665 849	Datablad		Installation instruction	EC-Declaration
EMMA LED SUSPENSION KIT	96 628 615	Datablad			
EMMA LED 1200 4000 840	96 666 098	Datablad	Fotometri	Installation instruction	EC-Declaration
EMMA LED 1500 6000 840	96 666 099	Datablad	Fotometri	Installation instruction	EC-Declaration
EVE LED Q596 3400 840 E3	96 628 611	Datablad	Fotometri	Installation instruction	EC-Declaration
EVE LED SUSPENSION KIT	96 628 616	Datablad			
EVE LED Q596 3400 830	96 628 837	Datablad	Fotometri	Installation instruction	EC-Declaration
EVE LED Q622 3400 830	96 628 838	Datablad	Fotometri	Installation instruction	EC-Declaration
EVE LED Q596 SLIM SURFACE MOUNT BOX	96 628 854	Datablad		Installation instruction	
EVE LED Q622 SLIM SURFACE MOUNT BOX	96 628 855	Datablad		Installation instruction	
EVE LED Q596 SURFACE MOUNT BOX	96 628 856	Datablad		Installation instruction	
EVE LED Q596 3400 840	96 666 096	Datablad	Fotometri	Installation instruction	EC-Declaration
EVE LED Q622 3400 840	96 666 097	Datablad	Fotometri	Installation instruction	EC-Declaration
HUGO IndiLouver LED 606 3500 HF L830	22 662 554	Datablad	Fotometri	Installation instruction	EC-Declaration
HUGO IndiLouver LED 606 3700 HF L840	22 662 555	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1500 LED IP65 4000 840	96 628 396	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1500 LED IP65 4000 840 E3	96 628 397	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 600 LED IP65 1800 840	96 628 548	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1200 LED IP65 4000 840	96 665 577	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1200 LED IP65 4000 840 CONNECT	96 665 578	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1200 LED IP65 4000 840 E3	96 665 579	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1500 LED IP65 6000 840	96 665 580	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1500 LED IP65 6000 840 CONNECT	96 665 581	Datablad	Fotometri	Installation instruction	EC-Declaration
JULIE 1500 LED IP65 6000 840 E3	96 665 582	Datablad	Fotometri	Installation instruction	EC-Declaration





Description	Article no.	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA Tamperproof Screw Kit	96 628 612	Datablad			
LARA LED 250 800 840 WH	96 666 101	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 BLK	96 666 102	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 WH E3	96 666 103	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 BLK E3	96 666 104	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 WH	96 666 105	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 BLK	96 666 106	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 WH E3	96 666 107	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 BLK E3	96 666 108	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 MWS WH	96 666 109	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 MWS BLK	96 666 110	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 MWS WH E3	96 666 111	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 MWS BLK E3	96 666 112	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 MWS WH	96 666 113	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 MWS BLK	96 666 114	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 MWS WH E3	96 666 115	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 MWS BLK E3	96 666 116	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 PC WH	96 666 117	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 250 800 840 PC BLK	96 666 118	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 PC BLK	96 666 119	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA LED 300 1200 840 PC WH	96 666 120	Datablad	Fotometri	Installation instruction	EC-Declaration
LARA BEZEL TRIM SMALL 250 WH	96 666 121	Datablad			
LARA BEZEL TRIM LARGE 300 WH	96 666 122	Datablad			
LARA BEZEL TRIM SMALL 250 BLK	96 666 123	Datablad			
LARA BEZEL TRIM LARGE 300 BLK	96 666 124	Datablad			
LARA EYELID TRIM SMALL 250 BLK	96 666 125	Datablad			
LARA EYELID TRIM LARGE 300 BLK	96 666 126	Datablad			
LARA EYELID GRILLE TRIM SMALL 250 BLK	96 666 127	Datablad			
LARA EYELID GRILLE TRIM LARGE 300 BLK	96 666 128	Datablad			
LARA GRILLE TRIM SMALL 250 BLK	96 666 129	Datablad			
LARA GRILLE TRIM LARGE 300 BLK	96 666 130	Datablad			
MIKE Minilux2 LED 1800 830 HF L1170	96 644 483	Datablad	Fotometri	Installation instruction	EC-Declaration
MIKE Minilux2 LED 1800 840 HF L1170	96 644 484	Datablad	Fotometri	Installation instruction	EC-Declaration
MIKE Minilux2 LED 900 830 HF L570	96 644 485	Datablad	Fotometri	Installation instruction	EC-Declaration
MIKE Minilux2 LED 900 840 HF L570	96 644 486	Datablad	Fotometri	Installation instruction	EC-Declaration
MONTY Moduline LED 606 3200 HF L840 E3	22 170 104	Datablad	Fotometri	Installation instruction	EC-Declaration
MONTY Moduline LED 606 3200 HF L830	22 662 551	Datablad	Fotometri	Installation instruction	EC-Declaration
MONTY Moduline LED 606 3200 HF L840	22 662 560	Datablad	Fotometri	Installation instruction	EC-Declaration

Description	Article no.	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED 300 1200 840 WH	96 666 080	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED 300 1200 840 BLK	96 666 081	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED 300 1200 840 MWS WH	96 666 082	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED 300 1200 840 MWS BLK	96 666 083	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED EYE 300 900 840 WH	96 666 084	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED EYE 300 900 840 BLK	96 666 085	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED EYE 300 900 840 MWS WH	96 666 086	Datablad	Fotometri	Installation instruction	EC-Declaration
TOM LED EYE 300 900 840 MWS BLK	96 666 087	Datablad	Fotometri	Installation instruction	EC-Declaration
ZOE LED DL 110 600 840	96 666 088	Datablad	Fotometri	Installation instruction	EC-Declaration
ZOE LED DL 160 900 840	96 666 089	Datablad	Fotometri	Installation instruction	EC-Declaration
ZOE LED DL 210 1500 840	96 666 090	Datablad	Fotometri	Installation instruction	EC-Declaration
ZOE LED DL 110 600 830	96 666 092	Datablad	Fotometri	Installation instruction	EC-Declaration
ZOE LED DL 160 900 830	96 666 093	Datablad	Fotometri	Installation instruction	EC-Declaration
ZOE LED DL 210 1500 830	96 666 094	Datablad	Fotometri	Installation instruction	EC-Declaration

